

Boston Whaler Heavy Duty Gun'l. Guard Kit - 9' - 17' Models

Part #	Qty	Description
0859335	1	INSERT, RUB RAIL BLACK FLEX 37'
1040161	2	ANCHOR, SCREW PLASTIC
1054816	1	RUB RAIL, VYNIL RIGID MOONSTONE 37" COILED
1054832	1	RUB RAIL, VYNIL FLEX MOONSTONE 37'
	2	WASHER, FINNISH #10
	86	POP RIVETS
	2	#10 OVAL HEAD SCREW

Instructions

1. Remove old vinyl. Note: If boat has chock, remove and after installing new rub rail, re-install the bow chock
2. Install flexible vinyl (A)
3. Install vinyl rigid (B)
4. Insert rub rail (C)
5. Round Corner (E)
6. Trim Back Ribs (D)
7. Fasten end (G)

Flexible Vinyl (A) covers old glue. Stretch Taut around boat to remove wrinkles. Tape To hold.

Rigid vinyl (B). Note pop rivet spacing below and install as shown. Use 13/64 drill for pop rivets. Tool for setting pop rivets is available le at most marine stores.

Rub rail (C) . Heating in sun or hot water will ease installation. Mallet may be used with care.

